



2006-2011 Honda Civic Front Brake Pad and Rotor Replacement

A video tutorial on how to change the old worn out and possibly noisy brake pads and rotor on a 2006-2011 Honda Civic.

Written By: eCuration



INTRODUCTION

If you are experiencing poor braking performance on your Honda Civic it may be time to replace them. A loud noise as well as pulsing break can also be an indication that the job needs to be tackled.

This video guide will walk you through it with ease.



TOOLS:

- [Hydraulic Floor Jack](#) (1)
- [Jack Stand](#) (1)
- [Torque Wrench](#) (1)
- [3/8" Drive Ratchet](#) (1)
- [Socket 19mm](#) (1)
- [17 mm Socket](#) (1)
- [12 mm Socket](#) (1)
- [17 mm Box End Wrench](#) (1)
- [12mm Wrench](#) (1)
- [Phillips 3 Screwdriver](#) (1)
- [Phillips #2 Screwdriver](#) (1)
- [6 Inch C-Clamp](#) (1)
- [Hammer](#) (1)
- [Anti-Seize Lubricant](#) (1)
- [Aerosol Brake Cleaner](#) (1)



PARTS:

- [Brake Rotor](#) (2)
- [Front Brake Pads](#) (2)

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-09-20 08:24:29 PM.